Gold Medal Hot Dog Steamer



Operating

- 1. Place the machine on a level surface.
- 2. Remove the hot dog basket and juice tray and add 10 quarts of hot water into heating compartment so that the water level is above heating element.

Do not overfill!

- 3. Replace the hot dog basket and juice tray.
- 4. Arrange hot dogs in the small compartment and buns in the large compartment, making sure there is free circulation of steam.
- 5. Turn the switch to ON and set the thermostat to HIGH until steam is generated.
- 6. After steam starts, set thermostat near the center of the range, between HIGH and LOW.
- 7. Keep lid closed when not serving.
- 8. Add hot water as needed to maintain steam production.

<u>Cleaning</u>

- 1. Unplug the machine.
- 2. Remove any remaining hot dogs and buns.
- 3. Wait until machine and water have cooled.
- 4. Drain the water through the drain pipe.
- 5. Wipe out the inside with a damp cloth.

Tips

- Avoid cool air hitting the warm surface of the machine, as it will cause condensation.
- If the hot dog casings burst, there is too much steam. Adjust the thermostat to a lower setting.
- If buns are too soggy, adjust the thermostat lower.
- If buns are too dry, adjust the thermostat higher.